

## **Occupational radiation protection for interventionalists: A joint Guideline of the Cardiovascular and Interventional Radiology Society of Europe and the Society of Interventional Radiology**

Donald L. Miller, M.D.  
Department of Radiology  
Uniformed Services University  
Bethesda, MD, U.S.A.

Eliseo Vañó, Ph.D.  
Complutense University  
San Carlos University Hospital and Radiology Department  
Madrid, SPAIN

Gabriel Bartal, M.D.  
Department of Diagnostic and Interventional Radiology  
Meir Medical Center  
Kfar Saba, ISRAEL

Stephen Balter, Ph.D  
Columbia University Medical Center  
New York, NY, U.S.A.

Robert Dixon, M.D.  
Department of Radiology  
University of North Carolina  
Chapel Hill, NC, U.S.A.

Renato Padovani, Ph.D.  
Azienda Ospedaliero-Universitaria S. Maria della Misericordia  
SOC di Emodinamica Piazzale S. Maria della Misericordia  
Udine, ITALY

Beth Schueler, Ph.D.  
Department of Radiology  
Mayo Clinic  
Rochester, MN, U.S.A.

John F. Cardella, M.D.  
Department of Radiology  
Geisinger Health System  
Danville, PA, U.S.A.

Thierry de Baère, M.D.  
Department of Interventional Radiology  
Institut Gustave-Roussy  
Villejuif, FRANCE

## Introduction

Fluoroscopically guided interventional procedures are performed in large numbers in Europe and in the United States. The number of procedures performed annually throughout the world has increased over the past 20 years.(1) The benefits of interventional radiology to patients are both extensive and beyond dispute, but many of these procedures also have the potential to produce patient radiation doses high enough to cause radiation effects and occupational doses to interventionalists high enough to cause concern.(1-4) A joint Society of interventional radiology (SIR) – Cardiovascular and Interventional Radiology Society of Europe (CIRSE) guideline on patient radiation management has addressed patient issues.(3) This guideline is intended to serve as a companion to that document, and provides guidance to help minimize occupational radiation dose.

The radiation dose received by interventionalists can vary by more than an order of magnitude for the same type of procedure and for similar patient dose.(4) Recently, there has been particular concern regarding occupational dose to the lens of the eye in interventionalists.(2) New data from exposed human populations suggest that lens opacities (cataracts) occur at doses far lower than those generally assumed to cause cataracts.(5, 6) If there is a threshold dose, it is possible that it is less than 0.1 Gy.(7, 8) The data are consistent statistically with the absence of a dose threshold.(7, 8) It appears that the latency period for radiation cataract formation is inversely related to radiation dose.(5)

Occupational radiation protection is a necessity whenever radiation is used in the practice of medicine. It is especially important for radiation-guided medical procedures.(4, 9) These procedures may involve high radiation dose rates in the interventional laboratory.(10, 11) Occupational radiation protection is necessary not only during fluoroscopically guided procedures but also during CT fluoroscopy. The radiation protection concerns for CT fluoroscopy differ somewhat, particularly in terms of avoiding excessive radiation dose to the interventionalist's hands.(12, 13)

Effective occupational radiation protection requires appropriate education and training for the interventionalist and the availability of appropriate protection tools and equipment. Occupational radiation protection measures must also comply with local and national regulations and should also consider the ergonomic detriment caused by personal protective devices.(13-17)

Occupational radiation protection measures are necessary for all individuals who work in the interventional fluoroscopy suite. This includes not only technologists and nurses, who spend a substantial amount of time in a radiation environment, but also individuals such as anesthesiologists who may be in a radiation environment only occasionally. All workers require appropriate monitoring,

protection tools and equipment and education and training appropriate to their jobs.(14) The level of training should be risk-based.

This Guideline is intended to offer a basic review of the medical physics relevant to occupational radiation safety and to provide advice and guidance to interventional radiologists who perform procedures with the guidance of ionizing radiation. In this document, the emphasis is radiation protection during fluoroscopically guided procedures.

### **Measurement of occupational exposure**

Quantities and units. International organizations have published recommendations on the quantities and units that should be used in occupational dosimetry.(15, 16) National regulations provide specific requirements for personal dosimetry in interventional practice. Dose limits to workers are expressed in term of effective dose (E) for whole body exposure and equivalent dose in an organ or tissue ( $H_T$ ), for exposure of part of the body. The SI unit for both quantities is the sievert (Sv).

Equivalent dose and effective dose cannot be measured directly. They must be calculated from other, simpler quantities that can be measured with personal dosimeters. Equivalent dose is the mean absorbed dose in a tissue or organ T multiplied by a radiation weighting factor  $w_R$ . For diagnostic x-rays,  $w_R = 1$ , so the absorbed dose and the equivalent dose are numerically equal. Effective dose is the weighted sum of the equivalent doses in all specified tissues and organs of the body. These tissue weighting factors,  $w_T$ , are highest for red bone marrow, breast, colon, lung and stomach, and lowest for cortical bone, salivary glands, brain and skin (15).

A typical personal dosimeter provides two values,  $H_p(0.07)$  and  $H_p(10)$ . These represent the dose equivalent in soft tissue at 0.07 mm and 10 mm below the surface of the body at the location of the dosimeter.(15)  $H_p(0.07)$  from the collar dosimeter worn over protective garments (apron, thyroid shield) provides a reasonable estimate of the dose delivered to the surface of the unshielded skin and to the lens of the eye. Consultation with a qualified medical physicist is recommended if the collar dosimeter is used to estimate dose to the lens of the eye. In Europe,  $H_p(10)$  from the dosimeter worn on the anterior chest inside protective garments is assumed to be a good estimate of the operator's effective dose, and was previously considered an adequate indicator of the health detriment from radiation exposure. A single under-lead dosimeter does not provide any information about eye dose.

The formula used to estimate E from dosimeter data may be specified by national regulations or by local hospital policy. When a protective apron is worn during diagnostic and interventional medical procedures using fluoroscopy, the National

Council on Radiation Protection and Measurements (NCRP) recommends combining the  $H_p(10)$  values from both body and collar dosimeters to estimate effective dose:

$$E (\text{estimate}) = 0.5 H_W + 0.025 H_N$$

where  $H_N$  = the reading from the dosimeter at the neck, outside the protective apron, and  $H_W$  = the reading from the dosimeter at the waist or on the chest, under the protective apron.(17)

Uncertainties in occupational dosimetry. All formulas used to estimate E from dosimeter readings are based on certain assumptions about the wearer's radiation protective garments. For safety reasons, most of the commonly used formulas overestimate the individual's actual effective dose. The various formulas, and their associated inaccuracies, are discussed in NCRP Report 122.(17) The formula given above is unlikely to underestimate E by more than a few percent or overestimate it by more than 100%.(17)

Personal dosimeters in the interventional laboratory are exposed to a radiation field composed of both x-rays that irradiate the dosimeter directly and radiation reflected or scattered back from the wearer's body. Accuracy and precision are affected by factors that influence the amount of radiation reaching the dosimeter from these two sources compared to the calibration conditions. Additional uncertainties arise because of the differences between monitor calibration conditions and the radiation environment in an interventional laboratory. The NCRP has published a full report on dosimetric uncertainty.(18)

Inaccurate dosimetry results arise from mistakes or omissions made by those involved in the overall logistical chain of events of the monitoring program. These include wearing the dosimeter inappropriately or in the wrong location on the body, leaving the dosimeter in a radiation environment, etc. Individuals may also forget to wear or purposely not wear their dosimeter. These actions result in an incorrect value for E and make it impossible to determine the user's true occupational risk.(18)

### **Occupational dosimetry in the interventional laboratory**

Dosimeter use. Radiation workers are monitored to determine their level of exposure. In order to allow adequate time for identification of practices leading to high personal dose and implementation of work habit changes, monthly monitor replacement is recommended for operators conducting interventional procedures. In some jurisdictions, monthly monitor replacement is mandatory.

Several international and national organizations have published recommendations on occupational dosimetry that are applicable to workers in interventional

laboratories. The relatively high occupational exposures in interventional radiology require the use of robust and adequate monitoring arrangements for staff. The International Commission on Radiological Protection (ICRP) recommends that interventional radiology departments develop a policy that staff wear two dosimeters, one under the apron and one at collar level above the lead apron.(10) Hand doses may also be monitored, using an additional dosimeter.(19)

For pregnant workers, fetal dose is usually estimated using a dosimeter placed on the mother's abdomen, under her radiation protective garments. This dosimeter overestimates actual fetal dose because radiation attenuation by the mother's tissues is not considered.

Dose limits. Dose limits for occupational exposures are expressed in equivalent doses for deterministic effects in specific tissues, and as effective dose for stochastic effects throughout the body.

The occupational dose limits recommended by the ICRP have been adopted by most of the countries in the world, including the European Union and the U.S.(15) The limits are described slightly differently in the European Union and the U.S. In the European Union, the limit for effective dose is 20 mSv per year, averaged over defined periods of 5 years. The effective dose may not exceed 50 mSv in any one year. In the U.S., individual State governments set occupational dose limits. In most cases recommendations developed by the NCRP are used.(20) The NCRP recommends an occupational limit of 50 mSv in any one year and a lifetime limit of 10 mSv x age in years. While these recommendations are not identical, they result in very similar outcomes when applied.

Additional restrictions apply to the occupational exposure of pregnant women. For women who may be pregnant, the ICRP recommends that the standard of protection for the conceptus should be broadly comparable to that provided for members of the general public.(15) After a worker has declared her pregnancy, her working conditions should ensure that the additional dose to the embryo/fetus does not exceed about 1 mSv during the remainder of the pregnancy. In the U.S., the NCRP recommends a 0.5 mSv equivalent dose monthly limit for the embryo-fetus (excluding medical and natural background radiation) once the pregnancy is declared.(20)

Compliance is demonstrated using a dosimeter worn by the worker at waist level, inside all radiation protective garments, from the date the pregnancy is declared until delivery. The dosimeter must be evaluated monthly. Electronic dosimeters can be used to provide rapid access to data.(21) In those centers where two-dosimeter worker monitoring systems are used, workers who may become pregnant should wear their 'inside' monitor at waist level. Data from these 'inside' monitors provide an estimate of fetal dose from conception to declaration.

Workers whose 'inside' badges show an average dose  $< 0.1$  mSv/month are automatically in compliance with ICRP and NCRP recommendations.

The current limit for the annual equivalent dose to the lens of the eye is 150 mSv. This limit is under review by an ICRP Task Group, as there is evidence that it is too high.(3, 6, 7) The annual limit for the hands and feet is 500 mSv. The dose received by specific tissues such as the lens of the eye can be estimated by placing a dosimeter on or near the tissue of interest. The 'collar' badge is commonly used to estimate eye dose in interventional laboratories. This method is usually acceptable if the X-ray tube is mounted below the patient. It is not possible to accurately estimate an operator's hand dose using a body or wrist dosimeter because of the proximity of the hands to the X-ray beam. A ring badge is recommended to estimate hand dose.(19)

Risk estimates. Effective dose (E) is intended to be proportional to the risk of radiation-induced cancer. The ICRP and NCRP occupational limits and limits for the general public are stated in terms of effective dose. (The ICRP refers to these values as dose limits; the NCRP refers to them as maximum permissible dose [MPD].) From a radiation safety point of view, a worker who receives a radiation dose less than or equal to the dose limit or MPD every year is in a safe occupation. Interventional radiologists are unavoidably irradiated in the performance of their duties. A busy interventionalist who takes all appropriate radiation safety precautions is unlikely to have an E exceeding 10 mSv/y, and is more likely to have an E of 2 - 4 mSv/y.(22-25) These values are well below the European dose limits and U.S. MPD. The risk to specific organs such as the fingers or the lens of the eye is related to the physical dose delivered to these tissues.

### **Evaluation of personal dosimetry data**

Personal dose records. The information in a personal dose record will vary depending on the number, type and location of personal dosimeters used. This record will contain information on the effective dose E, assessed from the readings of 1 or 2 dosimeters worn on the chest or abdomen under and/or over the lead apron, and may contain information on the equivalent dose to the lens of the eye from the dosimeter worn at the collar level over the apron or thyroid collar, and the equivalent dose to the hand from a ring or bracelet dosimeter.

Copies of these dose reports should be sent to each department and individual at least every year or, better, every reporting period. The relevant information contained in the dosimetry report to an individual includes the doses for the current period and the current year.

Surveillance of occupational dose. The facility's Radiation Safety section or Medical Physics Service should review the personal dose records of individual workers regularly. This review ensures that dose limits are not exceeded. It also

evaluates whether the dose received is at the level expected for that worker's particular duties. Workers' recorded dose levels should be compared to their own past dose levels and to the average dose levels of others doing similar work at the same facility or at other facilities. Typical staff dose readings for different types of procedures have been published in the literature.(11, 19, 26-36) Depending on the type of procedure and the technique used, the operator dose, per procedure, ranges from 3 – 450  $\mu\text{Sv}$  at the neck over protective garments, from  $<0.1$  – 32  $\mu\text{Sv}$  at the waist or chest under protective garments, and from 48 – 1280  $\mu\text{Sv}$  at the hand. Unfortunately, most of the published data are stated in terms of dose per procedure, and most of the data are for interventionalists rather than assistants, nurses, technologists or other staff. Translating these data into monthly or annual worker doses is difficult. As noted above, the effective dose for an interventionalist is typically 2 – 4 mSv/yr.(22-25)

Investigation of high occupational dose. The World Health Organization (WHO) recommends investigation when monthly exposure reaches 0.5 mSv for effective dose, 5 mSv for dose to the lens of the eye, or 15 mSv to the hands or extremities.(9) The Radiation Safety Officer or a medical physicist should contact the worker directly to determine the cause of the unusual dose and to make suggestions about how to keep the worker's dose as low as reasonably achievable (ALARA).

Badge readings for workers in interventional laboratories can be expected to be higher than for most other hospital workers. Most other hospital workers are expected to have minimal occupational radiation exposure. Using the same investigation criteria for both groups leads to non-productive investigations of interventionalists, and often to their reduced compliance with monitor use. ICRP publication 103 discusses how this situation may be avoided, by considering both the need for optimization of protection and the avoidance of arbitrary operational dose limits: "The use of prescriptive requirements should always be carefully justified. In any event, they should never be regarded as an alternative to the process of optimizing protection. It is not satisfactory to set design or operational limits or targets as an arbitrary fraction of the dose limit, regardless of the particular nature of the plant and the operations."(15)

Investigation of a high personal dose value begins with a check of the validity of the dosimeter reading. Potential sources of invalid dosimeter readings include wearing designated under- and over-protective apron dosimeters in the wrong location, wearing of a different worker's dosimeter and dosimeter storage in a location where it is exposed to radiation. If an invalid reading is suspected, the reading for the individual's next monitoring period should be reviewed to ensure the problem has been corrected.

If the dosimeters have been stored and worn correctly, the worker will be asked if there was a change in work habits that could explain the increase in radiation

exposure. Was a new type of procedure initiated during the monitoring period? Were procedure techniques or equipment settings modified? If so, did these new methods require increased patient dose or closer proximity to the patient? Did procedure workload or complexity increase? Sometimes, a temporary cause is found. If this is the case, dose levels should return to usual levels during the next monitoring period, when workload returns to normal, equipment settings are corrected, or there is additional experience with a new procedure or technique. The individual's dose reading for the next monitoring period should be reviewed to ensure that dose levels have returned to the expected range.

If the cause is not thought to be temporary, or if no cause can be identified, the individual's working habits should be observed during a series of representative procedures. The observer could be a medical or health physicist or a physician colleague with knowledge of radiation protection principles and the operation of the specific imaging equipment being used. The observer should pay close attention to equipment settings (particularly those that affect patient dose and dose-area-product), the worker's proximity to the patient, and the use of equipment mounted shields and personal protective devices. While individual workers may be able to assess their own working habits, an external observer has a different perspective and can point out otherwise unrecognized practices that result in high exposure levels.

Once the cause(s) of high personal dose levels have been identified, and changes to work practices implemented, it can be helpful for the individual to wear a real-time dosimeter to provide frequent feedback of radiation dose levels. With adequate cooperation and attention to dose reduction principles, forced limitation of workload to ensure compliance with dose limit is generally not needed.

Unusual situations may exist where compliance with recommended occupational dose limits in the interventional laboratory is impossible, *even with the use of fully optimized radiation protection*. The NCRP has discussed this in Report 116: "There may exist, however, unusual occupational situations in which the worker population cannot carry out required functions under the recommended annual limits and, in which, risks other than radiation may be much larger than normal. ... In these situations, the main concern also would be for the accumulated exposure of individuals over their working lifetime and thus a career limit would be of special importance."(20)

### **Radiation Protection Tools**

The greatest source of radiation exposure to the operator and staff is scatter from the patient. Generally, controlling patient dose also reduces scatter and limits operator dose. However, chronic radiation exposure in the work place mandates the use of protective tools in order to limit occupational radiation dose to an

acceptable level. The purpose of radiation protection tools is to improve operator and staff safety without impeding the procedure or jeopardizing the patient's safety.

Shielding. There are three types of shielding: architectural shielding, equipment mounted shields, and personal protective devices. Architectural shielding is built into the walls of the procedure room. This type of shielding is not discussed further here. In addition, rolling and stationary shields which rest on the floor, constructed of transparent leaded plastic, are available and are useful for providing additional shielding for both operators and staff. They are particularly well suited for use by nurses and anesthesia personnel.(37)

Equipment-mounted shielding includes protective drapes suspended from the table and from the ceiling. Table-suspended drapes hang from the side of the patient table, between the under-table x-ray tube and the operator. They should always be employed, as they have been shown to substantially reduce operator dose.(38) Unfortunately, they sometimes cannot be used if the x-ray gantry (C-arm) is in a steep oblique or lateral position.

Ceiling-suspended shields, generally constructed of a transparent leaded plastic, should also be used during cases of any significant length. Properly placed shields have been shown to dramatically reduce operator eye dose.(39, 40) It now appears that the threshold dose for cataract formation can be reached within several years for a moderately busy practitioner, so suspended shields or some other form of eye protection should be used by anyone performing interventional procedures on a regular basis.(2) Lens injuries have been reported in both operators and staff when systems which lack ceiling-suspended shields are used for complex interventional procedures.(41)

Disposable, protective patient drapes are now available. These contain metallic elements (bismuth or tungsten-antimony) and are placed on the patient after the operative site has been prepared and draped.(42, 43) They have been shown to reduce operator dose substantially, with reported reductions of 12-fold for the eyes, 26-fold for the thyroid and 29-fold for the hands.(43) While their use adds some cost to the procedure, disposable protective drapes should be considered for complex procedures and procedures where the operator's hands must be near the radiation field (e.g., management of dialysis fistulas and grafts, biliary interventions).(43)

Personal protective devices. Personal protective devices include aprons, thyroid shields, eyewear, and gloves. Protective aprons with thyroid shields are the principal radiation protection tool for interventional workers. They should be employed at all times. The vest/skirt configuration is preferred by many operators in order to reduce the risk of musculoskeletal/back injury.(44) These are typically 0.25 mm lead-equivalent, so that when worn they provide 0.5 mm lead-equivalent

anteriorly. Operators and staff who work in the interventional laboratory on a regular basis should be provided with properly fitted aprons, both to reduce ergonomic hazards and to provide optimal radiation protection.(45)

Because of the ergonomic hazards of personal protective devices (particularly leaded aprons), attempts to reduce the fatigue and injury associated with wearing heavy protective apparel have been made. (44) An early version of a “weightless apron” involved a rolling device from which the apron was hung. This was positioned behind the operator and rolled as the interventionalist moved.(46) A newer iteration, recently introduced, travels on a set of ceiling mounted rails and is easily donned within seconds.(47) This newer device extends from the head to the distal portions of the lower extremities and provides substantial protection to the wearer. Devices such as these hold promise for improved ergonomics and safety.

Since the current ICRP occupational limit for eye exposure of 150 mSv/year may be too high, and since radiation cataract formation may be a stochastic effect, operators are strongly advised to use eye protection at all times.(2, 15) Leaded eyeglasses are an alternative to ceiling-suspended shields for this purpose. Leaded eyeglasses with large lenses and protective side shields provide more protection than eyeglasses without these features. They help to minimize scatter which approaches the operator from the side and scatter from the operator’s own head.(48) The principal disadvantage of leaded eyeglasses is their weight and discomfort.

In general, the operator’s hands should be kept out of the primary radiation beam. Leaded gloves may seem useful for radiation protection on those rare occasions when the operator’s hands must be in the primary radiation beam, but they are not. Because of scatter created within the glove, the increased dose when any shielding is placed in the primary beam, and the false sense of security that they provide, protective gloves can result in increased radiation dose to the hand when it is in the primary beam.(49) They are not recommended in this situation. The best way to protect the operator’s hands is to keep them out of the radiation field. Leaded gloves may be of benefit if the operator’s hands will be near, but not in, the primary radiation beam.

Effectiveness of shielding. The shielding material for protective aprons has evolved from heavy, lead-impregnated vinyl or rubber with a shielding equivalent of 1 mm of lead, to lighter, composite (lead plus other high atomic-numbered elements) or entirely lead-free materials. These lighter materials have largely replaced the all-lead aprons of the past, and typically are designed to provide 0.5 mm lead-equivalent protection anteriorly.(50) Transmission of 70 – 100 kVp x-rays through 0.5 mm lead is approximately 0.5 - 5%.(22, 51) The protection provided by 0.5mm lead-equivalent composite and lead-free aprons has been found to vary, and ranges from 0.6 – 6.8% transmission.(51)

Leaded glasses reduce the dose to the operator's eye from frontal exposure by a factor of approximately 8 – 10.(40, 52) When side exposure is included (the typical situation in clinical practice), the protection factor is decreased to between 2 and 3.(53) Combining various types of shielding (i.e., table-suspended drapes, ceiling-suspended screens, aprons, leaded glasses, mobile shields, and disposable drapes) results in dramatic dose reduction for the operator.(37, 40) This should be the norm, rather than the exception.

Scatter. Detailed discussion of scatter isodose curves is beyond the scope of this document. Readers are directed to the extensive work in the literature.(2, 54-56) The magnitude and distribution of scattered radiation is affected by many factors, including patient size, gantry angulation, patient position, filtration, fluoroscopic settings, and the use of shielding. Overall, in an unshielded environment, and for a posteroanterior (PA) projection, the exposure is greatest below the table, less at the operator's waist level, and least at the eye level. However, substantial operator eye doses can be reached in unfavorable circumstances (large patient, high dose fluoroscopy/fluorography, gantry angulation) underscoring the importance of proper protection, particularly for the eyes.(2, 54, 56, 57)

### **Practical advice to reduce minimize occupational radiation dose**

Decreasing patient dose will result in a proportional decrease in scatter dose to the operator. Therefore, techniques that reduce patient dose will generally also reduce your occupational dose. This is a "win-win" situation; you and your patient both benefit. Additional techniques can also be used to reduce occupational dose. Both types of techniques are listed in table 1 and described in more detail below.

#### 1. Minimize fluoroscopy time

Fluoroscopy should be used only to observe objects or structures in motion. Review the last-image-hold for study, consultation or education instead of additional fluoroscopic exposure. If available, use fluoroscopy loop recording to review dynamic processes. Use short taps of fluoroscopy instead of continuous operation. Fluoroscopy to determine or adjust collimator blade positioning can be eliminated by using the virtual collimation feature, when present.

#### 2. Minimize the number of fluorographic images

For digital subtraction angiography, use variable frame rates tailored to the examination (e.g., 1 image/sec for 6 seconds, then 1 image every other second for 24 seconds for arteriography of the celiac axis) instead of a constant frame rate (e.g., 2 images/second for 30 seconds). Suggested imaging sequences are available in some older standard textbooks.(58, 59) For documentation, use stored last-image-hold images instead of acquiring additional images. When available, use a stored fluoroscopy loop instead of a fluorographic acquisition.

#### 3. Use available patient dose reduction technologies

These include low fluoroscopy dose rate settings, low frame rate pulsed fluoroscopy, removal of the anti-scatter grid, spectral beam filtration and use of increased x-ray beam energy. Improved image processing within the fluoroscopic unit can compensate to a considerable degree for the reduced image quality due to decreased exposure levels. Catheters with highly radiopaque tips are easier to see. Children and some small adults can be imaged without the anti-scatter grid. This technique reduces dose at the cost of somewhat decreased image quality.

#### 4. Use good imaging-chain geometry

Position the patient support so that the patient is as far as possible from the x-ray tube. Place the image receptor as close as possible to the patient.

#### 5. Use collimation

Adjust collimator blades tightly to the area of interest. Tight collimation reduces patient dose and improves image quality by reducing scatter. When beginning a case, position the C-arm over the area of interest, with the collimators almost closed. Open the collimators gradually until the desired field of view is obtained.

#### 6. Use all available information to plan the interventional procedure

When appropriate, use pre-procedure imaging (ultrasound, MRI, CT) to define the relevant anatomy and pathology and to plan the interventional procedure.

#### 7. Position yourself in a low scatter area

Stay as far away from the x-ray beam as possible. Use tubing extensions or needle holders so that your hands are away from the exposed field. Never place your hands in the x-ray beam. Use power injectors for contrast material injections when feasible, and step out of the procedure room during fluorographic acquisitions (digital subtraction angiography). When using angulated or lateral projections, keep in mind that the highest intensity of scattered radiation is located on the x-ray beam entrance side of the patient. When using these projections, the x-ray tube should be on the side opposite the operator whenever possible. Never use equipment with over-the-table x-ray tubes for interventional procedures.

#### 8. Use protective shielding

When you perform fluoroscopically guided interventions, you should wear a personal protective apron and a thyroid shield. Ceiling-suspended shields can provide significant additional dose reduction, especially to unprotected areas of your head and neck. Leaded eyewear is recommended if ceiling-suspended shields are not used. Under-table lead drapes reduce lower extremity dose substantially, and should be used whenever possible.

#### 9. Use appropriate fluoroscopic imaging equipment

Imaging systems optimized for one type of procedure or body part may be suboptimal for others. Using fluoroscopy equipment under suboptimal conditions frequently results in increased radiation dose. Furthermore, high radiation dose procedures should be performed with fluoroscopic systems that incorporate recommended dose-reduction technology and comply with the most current International Electrotechnical Commission standards.(60) Encourage your institution to purchase this kind of equipment for interventional laboratories.

#### 10. Obtain appropriate training

You and all staff involved in the procedure should have a general knowledge of safe operating practices in a radiation environment. You should be thoroughly familiar with the operation of the particular fluoroscopy equipment you are using. If appropriate medical simulators are available, you should consider using them to learn and practice new skills before you apply them to patients.

#### 11. Wear your dosimeters and know your own dose!

You need to know your occupational dose in order to ensure that you are working safely. Your dose data will not be accurate unless you always wear your dosimeters, and wear them correctly.

### **Management responsibilities.**

Management should provide an appropriate level of resources, such as staff, facilities and equipment, to ensure that radiation dose is adequately controlled. Facilities and equipment include, but are not limited to, shielding, radiation monitoring instruments, protective clothing, etc. Quality assurance is an essential component of any monitoring program.(61) Occupational doses should be analyzed by each department, and high doses and outliers should be investigated.

Protective aprons should be examined fluoroscopically every year and inspected visually on a daily or weekly basis for damage and defects (51). Standardized methods for acceptance testing of protective aprons are needed, due to the wide variation in actual attenuation values of aprons (50, 51).

Adequate and relevant training programs should be provided for all levels of staff within the organization, including management, to develop a commitment to radiological protection and in order that all concerned can contribute to the reduction and control of exposures.(61)

Table 1.  
Key points for safe practice

- Minimize fluoroscopy time
- Minimize the number of fluorographic images
- Use available patient dose reduction technologies
- Use good imaging-chain geometry
- Use collimation
- Use all available information to plan the interventional procedure
- Position yourself in a low scatter area
- Use protective shielding
- Use appropriate fluoroscopic imaging equipment
- Obtain appropriate training
- Wear your dosimeters and know your own dose!

See text for details

## References

1. Miller DL. Overview of contemporary interventional fluoroscopy procedures. *Health Phys* 2008; 95:638-644.
2. Vano E, Gonzalez L, Fernández JM, Haskal ZJ. Eye lens exposure to radiation in interventional suites: caution is warranted. *Radiology* 2008; 248:945-953.
3. Stecker MS, Balter S, Towbin RB, et al. Guidelines for patient radiation dose management. *J Vasc Interv Radiol* 2009; 20:S263-S273.
4. Kim KP, Miller DL, Balter S, et al. Occupational radiation doses to operators performing cardiac catheterization procedures. *Health Phys* 2008; 94:211-227.
5. Kleiman NJ. Radiation cataract. In: Working Party on Research Implications on Health and Safety Standards of the Article 31 Group of Experts, ed. *Radiation Protection 145. EU Scientific Seminar 2006. New insights in radiation risk and basic safety standards*. Brussels: European Commission, 2007; 81-95. Available at [http://ec.europa.eu/energy/nuclear/radioprotection/publication/doc/145\\_en.pdf](http://ec.europa.eu/energy/nuclear/radioprotection/publication/doc/145_en.pdf) Accessed August 16, 2009.
6. Worgul BV, Kundiyeve YI, Sergiyenko NM, et al. Cataracts among Chernobyl clean-up workers: implications regarding permissible eye exposures. *Radiat Res* 2007; 167:233-243.
7. Nakashima E, Neriishi K, Minamoto A. A reanalysis of atomic-bomb cataract data, 2000-2002: a threshold analysis. *Health Phys* 2006; 90:154-160.
8. Neriishi K, Nakashima E, Minamoto A, et al. Postoperative cataract cases among atomic bomb survivors: radiation dose response and threshold. *Radiat Res* 2007; 168:404-408.
9. World Health Organization. *Efficacy and radiation safety in interventional radiology*. Geneva: World Health Organization, 2000.
10. International Commission on Radiological Protection. *Avoidance of radiation injuries from medical interventional procedures*. ICRP Publication 85. *Ann ICRP* 2000; 30:7-67.
11. Vañó E, González L, Guibelalde E, Fernández JM, Ten JI. Radiation exposure to medical staff in interventional and cardiac radiology. *Br J Radiol* 1998; 71:954-960.
12. Stoeckelhuber BM, Leibecke T, Schulz E, et al. Radiation dose to the radiologist's hand during continuous CT fluoroscopy-guided interventions. *Cardiovasc Intervent Radiol* 2005; 28:589-594.
13. Hohl C, Suess C, Wildberger JE, et al. Dose reduction during CT fluoroscopy: phantom study of angular beam modulation. *Radiology* 2008; 246:519-525.
14. European Commission. *Radiation protection 116. Guidelines on education and training in radiation protection for medical exposures*. Luxembourg: European Commission. Directorate-General for the Environment, 2000. Available at: [http://ec.europa.eu/energy/nuclear/radiation\\_protection/doc/publication/116.pdf](http://ec.europa.eu/energy/nuclear/radiation_protection/doc/publication/116.pdf) Accessed August 16, 2009.

15. International Commission on Radiological Protection. The 2007 Recommendations of the International Commission on Radiological Protection. ICRP publication 103. Ann ICRP 2007; 37:1-332.
16. International Commission on Radiological Protection. Conversion coefficients for use in radiological protection against external radiation. Adopted by the ICRP and ICRU in September 1995. Ann ICRP 1996; 26:1-205.
17. National Council on Radiation Protection and Measurements. Use of personal monitors to estimate effective dose equivalent and effective dose to workers for external exposure to low-LET radiation. Report No. 122. Bethesda, MD: National Council on Radiation Protection and Measurements, 1995.
18. National Council on Radiation Protection and Measurements. Uncertainties in the measurement and dosimetry of external radiation: recommendations of the National Council on Radiation Protection and Measurements. Report No. 158. Bethesda, MD: National Council on Radiation Protection and Measurements, 2008.
19. Whitby M, Martin CJ. A study of the distribution of dose across the hands of interventional radiologists and cardiologists. Br J Radiol 2005; 78:219-229.
20. National Council on Radiation Protection and Measurements. Limitation of Exposure to Ionizing Radiation. Report No. 116. Bethesda, MD: National Council on Radiation Protection and Measurements, 1993.
21. Balter S, Lamont J. Radiation and the pregnant nurse. Cath Lab Digest 2002; 10:e1. Available at: <http://www.cathlabdigest.com/article/357> Accessed August 16, 2009
22. Marx MV, Niklason L, Mauger EA. Occupational radiation exposure to interventional radiologists: a prospective study. J Vasc Interv Radiol 1992; 3:597-606.
23. Tsapaki V, Kottou S, Vano E, et al. Occupational dose constraints in interventional cardiology procedures: the DIMOND approach. Phys Med Biol 2004; 49:997-1005.
24. Delichas M, Psarrakos K, Molyvda-Athanassopoulou E, et al. Radiation exposure to cardiologists performing interventional cardiology procedures. Eur J Radiol 2003; 48:268-273.
25. Dendy PP. Radiation risks in interventional radiology. Br J Radiol 2008; 81:1-7.
26. Stratakis J, Damilakis J, Hatzidakis A, Theocharopoulos N, Gourtsoyiannis N. Occupational radiation exposure from fluoroscopically guided percutaneous transhepatic biliary procedures. J Vasc Interv Radiol 2006; 17:863-871.
27. Layton KF, Kallmes DF, Cloft HJ, Schueler BA, Sturchio GM. Radiation exposure to the primary operator during endovascular surgical neuroradiology procedures. AJNR Am J Neuroradiol 2006; 27:742-743.
28. Stavas JM, Smith TP, DeLong DM, Miller MJ, Suhocki PV, Newman GE. Radiation hand exposure during restoration of flow to the thrombosed dialysis access graft. J Vasc Interv Radiol 2006; 17:1611-1617.

29. Lipsitz EC, Veith FJ, Ohki T, et al. Does the endovascular repair of aortoiliac aneurysms pose a radiation safety hazard to vascular surgeons? *J Vasc Surg* 2000; 32:704-710.
30. Buls N, Pages J, Mana F, Osteaux M. Patient and staff exposure during endoscopic retrograde cholangiopancreatography. *Br J Radiol* 2002; 75:435-443.
31. Sulieman A, Theodorou K, Vlychou M, et al. Radiation dose optimisation and risk estimation to patients and staff during hysterosalpingography. *Radiat Prot Dosimetry* 2008; 128:217-226.
32. Hellawell GO, Mutch SJ, Thevendran G, Wells E, Morgan RJ. Radiation exposure and the urologist: What are the risks? *J Urol* 2005; 174:948-952.
33. Botwin KP, Thomas S, Gruber RD, et al. Radiation exposure of the spinal interventionalist performing fluoroscopically guided lumbar transforaminal epidural steroid injections. *Arch Phys Med Rehabil* 2002; 83:697-701.
34. Harstall R, Heini PF, Mini RL, Orlor R. Radiation exposure to the surgeon during fluoroscopically assisted percutaneous vertebroplasty: A prospective study. *Spine* 2005; 30:1893-1898.
35. Kallmes DF, O E, Roy SS, et al. Radiation dose to the operator during vertebroplasty: prospective comparison of the use of 1-cc syringes versus an injection device. *AJNR Am J Neuroradiol* 2003; 24:1257-1260.
36. Synowitz M, Kiwit J. Surgeon's radiation exposure during percutaneous vertebroplasty. *J Neurosurg Spine* 2006; 4:106-109.
37. Luchs JS, Rosioreanu A, Gregorius D, Venkataramanan N, Koehler V, Ortiz AO. Radiation safety during spine interventions. *J Vasc Interv Radiol* 2005; 16:107-111.
38. Shortt CP, Al-Hashimi H, Malone L, Lee MJ. Staff radiation doses to the lower extremities in interventional radiology. *Cardiovasc Intervent Radiol* 2007; 30:1206-1209.
39. Maeder M, Brunner-La Rocca HP, Wolber T, et al. Impact of a lead glass screen on scatter radiation to eyes and hands in interventional cardiologists. *Catheter Cardiovasc Interv* 2006; 67:18-23.
40. Thornton RH, Altamirano J, Dauer L. Comparing strategies for IR eye protection [abstract]. *J Vasc Interv Radiol* 2009; 20:S52-S53.
41. Vañó E, González L, Beneytez F, Moreno F. Lens injuries induced by occupational exposure in non-optimized interventional radiology laboratories. *Br J Radiol* 1998; 71:728-733.
42. Dromi S, Wood BJ, Oberoi J, Neeman Z. Heavy metal pad shielding during fluoroscopic interventions. *J Vasc Interv Radiol* 2006; 17:1201-1206.
43. King JN, Champlin AM, Kelsey CA, Tripp DA. Using a sterile disposable protective surgical drape for reduction of radiation exposure to interventionalists. *Am J Roentgenol* 2002; 178:153-157.
44. Klein LW, Miller DL, Balter S, et al. Occupational health hazards in the interventional laboratory: time for a safer environment. *J Vasc Interv Radiol* 2009; 20:147-152; quiz 153.

45. Detorie N, Mahesh M, Schueler BA. Reducing occupational exposure from fluoroscopy. *J Am Coll Radiol* 2007; 4:335-337.
46. Pelz DM. Low back pain, lead aprons, and the angiographer. *AJNR Am J Neuroradiol* 2000; 21:1364.
47. Savage C, Carlson L, Clements J, Rees C. Comparison of the Zero Gravity system to conventional lead apron for radiation protection of the interventionalist. *J Vasc Interv Radiol* 2009; 20:S53.
48. Cousin AJ, Lawdahl RB, Chakraborty DP, Koehler RE. The case for radioprotective eyewear/facewear. Practical implications and suggestions. *Invest Radiol* 1987; 22:688-692.
49. Wagner LK, Mulhern OR. Radiation-attenuating surgical gloves: effects of scatter and secondary electron production. *Radiology* 1996; 200:45-48.
50. Finnerty M, Brennan PC. Protective aprons in imaging departments: manufacturer stated lead equivalence values require validation. *Eur Radiol* 2005; 15:1477-1484.
51. Christodoulou EG, Goodsitt MM, Larson SC, Darner KL, Satti J, Chan HP. Evaluation of the transmitted exposure through lead equivalent aprons used in a radiology department, including the contribution from backscatter. *Med Phys* 2003; 30:1033-1038.
52. Marshall NW, Faulkner K, Clarke P. An investigation into the effect of protective devices on the dose to radiosensitive organs in the head and neck. *Br J Radiol* 1992; 65:799-802.
53. Moore WE, Ferguson G, Rohrmann C. Physical factors determining the utility of radiation safety glasses. *Med Phys* 1980; 7:8-12.
54. Balter S. Radiation safety in the cardiac catheterization laboratory: basic principles. *Catheter Cardiovasc Interv* 1999; 47:229-236.
55. Whitby M, Martin CJ. Radiation doses to the legs of radiologists performing interventional procedures: are they a cause for concern? *Br J Radiol* 2003; 76:321-327.
56. Schueler BA, Vrieze TJ, Bjarnason H, Stanson AW. An investigation of operator exposure in interventional radiology. *Radiographics* 2006; 26:1533-1541.
57. Balter S, Sones FM, Brancato R. Radiation exposure to the operator performing cardiac angiography with U-arm systems. *Circulation* 1978; 58:925-932.
58. Kandarpa K, Aruny JE. Handbook of interventional radiologic procedures. 3rd ed. Philadelphia: Lippincott Williams & Wilkins, 2002.
59. Bakal CW. Vascular and interventional radiology: principles and practice. New York: Thieme, 2002.
60. International Electrotechnical Commission. Report 60601 Medical electrical equipment - Part 2-43: Particular requirements for the safety of X-ray equipment for interventional procedures. Geneva, Switzerland: International Electrotechnical Commission, 2000.
61. International Commission on Radiological Protection. General principles for the radiation protection of workers. Publication 75. *Ann ICRP* 1997; 27:1-60.